


SEALANT COVER
INSTALLS DIRECTLY
ABOVE SEALANT

FIELD SOLDERED
SEAMS - MODEL A/D
FACTORY SOLDERED
SEAMS - MODEL A/S

FIELD SOLDERED
SEAMS - MODEL A/D
FACTORY SOLDERED
SEAMS - MODEL A/S



ANGLE FLASHING - Models A/D (as shown) and A/S